

Occasionally, something will knock a generator off line. You won't hear it run its weekly test, and of course it won't come on if you have emergency power needs. The fix could be as easy as resetting your generator. Remove your generator's cover and follow the directions below.

To reset your Kohler controller, turn the unit **OFF** by pushing the blue **OFF** button and wait **30 seconds**. Next, push the blue **RUN** button. The generator will either start or attempt to start three times. If it starts, let it run 5 minutes and then push the blue **OFF** button again. Wait 30 seconds until it has completely shut down, then push the blue **AUTO** button which resets it to normal standby mode.



Try to reset your generator by this method for up to three times. If your generator does not come back online, call us at